

Orientalmotor

XF3000506

IP43/IP55 仕様フィルターメディア 装着／交換時の注意


いつも当社製品をご使用いただきありがとうございます。
ございます。

FM シリーズの IP43/IP55 仕様フィルターメディアは、目の粗い面から細かい面へ空気が流れるように装着してください。(目の細かい面の方が硬くなっています。)装着する方向を誤ると目詰まりしやすくなります。

また、ファン・フィルターパネルの吐出しタイプと吸込みタイプでは、装着の向きが異なります。以下のように装着してください。

吐出しタイプ：目の細かい面をフード側に装着

吸込みタイプ：目の粗い面をフード側に装着

**オリエンタルモーター株式会社****Orientalmotor**

XF3000506

IP43/IP55 仕様フィルターメディア 装着／交換時の注意


いつも当社製品をご使用いただきありがとうございます。
ございます。

FM シリーズの IP43/IP55 仕様フィルターメディアは、目の粗い面から細かい面へ空気が流れるように装着してください。(目の細かい面の方が硬くなっています。)装着する方向を誤ると目詰まりしやすくなります。

また、ファン・フィルターパネルの吐出しタイプと吸込みタイプでは、装着の向きが異なります。以下のように装着してください。

吐出しタイプ：目の細かい面をフード側に装着

吸込みタイプ：目の粗い面をフード側に装着

**オリエンタルモーター株式会社****Orientalmotor**

XF3000506

IP43/IP55 仕様フィルターメディア 装着／交換時の注意


いつも当社製品をご使用いただきありがとうございます。
ございます。

FM シリーズの IP43/IP55 仕様フィルターメディアは、目の粗い面から細かい面へ空気が流れるように装着してください。(目の細かい面の方が硬くなっています。)装着する方向を誤ると目詰まりしやすくなります。

また、ファン・フィルターパネルの吐出しタイプと吸込みタイプでは、装着の向きが異なります。以下のように装着してください。

吐出しタイプ：目の細かい面をフード側に装着

吸込みタイプ：目の粗い面をフード側に装着

**オリエンタルモーター株式会社****Orientalmotor**

XF3000506

IP43/IP55 仕様フィルターメディア 装着／交換時の注意


いつも当社製品をご使用いただきありがとうございます。
ございます。

FM シリーズの IP43/IP55 仕様フィルターメディアは、目の粗い面から細かい面へ空気が流れるように装着してください。(目の細かい面の方が硬くなっています。)装着する方向を誤ると目詰まりしやすくなります。

また、ファン・フィルターパネルの吐出しタイプと吸込みタイプでは、装着の向きが異なります。以下のように装着してください。

吐出しタイプ：目の細かい面をフード側に装着

吸込みタイプ：目の粗い面をフード側に装着

**オリエンタルモーター株式会社**

Notes on installation/replacement of IP43/IP55 filter media


Thank you for using an Oriental Motor product.
IP43/IP55 filters used with the **FM** series should be installed in the orientation that allows air to flow through the filter from the coarse side to the fine side (as an identification guide, the fine side is harder). If installed in the wrong orientation, the filter will clog easily.

Also, the installation orientation in the fan filter panel is different between the exhaust type and the suction type. Follow the instructions below:

Exhaust type: Install the filter so that the fine side faces the hood.

Suction type: Install the filter so that the coarse side faces the hood.

ORIENTAL MOTOR CO.,LTD.



Notes on installation/replacement of IP43/IP55 filter media


Thank you for using an Oriental Motor product.
IP43/IP55 filters used with the **FM** series should be installed in the orientation that allows air to flow through the filter from the coarse side to the fine side (as an identification guide, the fine side is harder). If installed in the wrong orientation, the filter will clog easily.

Also, the installation orientation in the fan filter panel is different between the exhaust type and the suction type. Follow the instructions below:

Exhaust type: Install the filter so that the fine side faces the hood.

Suction type: Install the filter so that the coarse side faces the hood.

ORIENTAL MOTOR CO.,LTD.



Notes on installation/replacement of IP43/IP55 filter media


Thank you for using an Oriental Motor product.
IP43/IP55 filters used with the **FM** series should be installed in the orientation that allows air to flow through the filter from the coarse side to the fine side (as an identification guide, the fine side is harder). If installed in the wrong orientation, the filter will clog easily.

Also, the installation orientation in the fan filter panel is different between the exhaust type and the suction type. Follow the instructions below:

Exhaust type: Install the filter so that the fine side faces the hood.

Suction type: Install the filter so that the coarse side faces the hood.

ORIENTAL MOTOR CO.,LTD.



Notes on installation/replacement of IP43/IP55 filter media

Thank you for using an Oriental Motor product.
IP43/IP55 filters used with the **FM** series should be installed in the orientation that allows air to flow through the filter from the coarse side to the fine side (as an identification guide, the fine side is harder). If installed in the wrong orientation, the filter will clog easily.

Also, the installation orientation in the fan filter panel is different between the exhaust type and the suction type. Follow the instructions below:

Exhaust type: Install the filter so that the fine side faces the hood.

Suction type: Install the filter so that the coarse side faces the hood.

ORIENTAL MOTOR CO.,LTD.

